

# Weighing In

A newsletter from Weigh Right

## Packaging Soap Tablets into Bags

For customers packaging products by piece count into a bag, Weigh Right offers our PMB-2-CT scale that features a 2-tray vibratory feed design that singulates the product directly into the weigh bucket. Using advanced Weigh/Count technology, the product is portioned accurately and quickly\*.

For dusty products, Weigh Right offers an optional dust hood that fully encloses the vibratory trays to contain the dust and maintain a cleaner workspace.

During production, the product is loaded at floor level into the IC-45 infeed conveyor's receiving hopper and elevated via cleated belt to the scale hopper. For fragile or delicate products, a food-grade rubber-lined hopper is available as an upgrade. The conveyor runs automatically, controlled by a level sensor for smooth, hands-free operation.

For filling the product into the bag, an operator simply slips a bag over a custom-sized fill spout for fast, ergonomic filling.

Watch our new video showcasing this fully integrated, automated system in action!

**See our new video of the PMB-2-CT.**

\*(typically 0 to 1 or 2 pieces over subject to product size and piece size consistency)



**Shown Above:** The PMB-2-CT with dust hood and food-grade rubber lined insert along with our IC-45 infeed conveyor.



# **WEIGH RIGHT**

*Automatic Scale Co.*

## PMB-2 SCALE

Using Weigh / Count Technology  
to portion out 40 soap tablets into bags

See our **new video** for more features.

Want more information, call Weigh Right at  
800-571-0249

Our mailing address is:

Weigh Right  
612-A Mills Rd.  
Joliet, IL 60433